

# FMTD64 Forbes Marshall Thermodynamic Trap

#### Description

The Forbes Marshall Thermodynamic Trap FMTD64, with inbuilt strainer and full stainless steel construction, is best suited for header and mainline drains.

#### Size and Pipe Connections

DN 15 and DN 20

Screwed BSPT/NPT/BSP and socket weldable ends **Notes** 

1. Available with Class 150,300 and 600 weld on flanges on request


2. Available with IBR certificate

# **Limiting Conditions**

Body design conditions	PN63
PMA Maximum allowable pressure	63 bar g
TMA Maximum allowable temperature	400°C @ 42 bar g
Minimum allowable temperature	0°C
PMO Maximum operating pressure	42 bar g
	recommended
TMO Maximum operating temperature	400°C @ 42 bar g
Minimum operating temperature	0°C
Minimum operating pressure	
for satisfactory operations	0.25 bar g
Designed for a maximum cold hydraulic	95 bar g
test pressure of	


**Note :** for lower operating temperatures consult Forbes Marshall

PMOB : Maximum back pressure should not exceed 80% of the inlet pressure under any conditions of operation otherwise the trap may not shut-off.




# **Optional Extras**


ISOTUB- An insulating cover which prevents the trap from being unduly influenced by excessive heat loss such as when subjected to low outside temperature, wind, rain etc.



#### Material

No	Part	Material	Standard
1.	Body	Stainless Steel	ASTM A 743 Gr-CA40
2.	Сар	Stainless steel	BS 3146 ANC 2
3.	Disc	Stainless steel	ASTM A 240 SS 420
4.	Strainer Screen	Stainless steel	ASTM A 240 Type 304
5.	Strainer cap	Stainless steel	BS 3146 ANC 2






#### Dimensions (approx.in mm)

Size	Α	В	С	D	E	Weight
DN 15						
DN 20	42	78	50	44	57	0.8 kg

# Salient Features

- 1. Complete stainless steel construction ensures better mechanical and corrosion resistant properties.
- 2. The disc and seat, hardened by induction hardening process to about 45RC can withstand continuous water hammering conditions.
- 3. Seat integral part of the body, eliminates leakage- prone joints and gaskets.
- 4. Condensate entry below the disc concentric to disc/seat ensures clean and parallel lift to disc with reference to seat, eliminating any localized wear and tear.
- 5. An inbuilt strainer screen of adequately large area ensures long and trouble free operation.

# **Capacity Chart**



ltem	Part	[]	Or mm	Nm
2	Spool	42	M3	5 180-200
5	Stud	32	M2	8 170-190

#### **Available Spares**

Strainer Screen and Disc (pkt. of 3)	A+B	
Isotub	С	

The spare parts available are shown in heavy outline. Parts drawn in broken line are not supplied as spares.

#### How to Order Spares

Always order spares by using the description given in the column headed "Available Spare" and stating the size and type of trap.

Example: 1No. Strainer Screen for DN15 Forbes Marshall Thermodynamic Trap FMTD64

**Opp 106th Milestone** 

Bombay Poona Road

Fax: 91(0)20-27147413

Kasarwadi, Pune - 411 034. INDIA

Tel: 91(0)20-27145595, 39858555

Email : seg@forbesmarshall.com, ccmidc@forbesmarshall.com



Forbes Marshall Krohne Marshall Forbes Marshall Arca Codel International Forbes Solar Forbes Vyncke Forbes Marshall Steam Systems

# How to Order

Example: 1No. DN15 Forbes Marshall Thermodynamic Trap FMTD64

# Installation

Preferably on horizontal pipe with cover on top. The trap can be fitted in other positions if unavoidable.


## Maintenance

Remove the isotub if fitted and unscrew cap using spanner. Do not use pipe wrench which may cause distortion of the cap. If the disc and body seating faces are only slightly worn they can be refaced by lapping individually on a flat surface such as a surface plate. A figure of eight motion and a diluted 1:6 lapping compound such as 6 micron Aluminium Oxide gives the best results.

If the wear is too great to be rectified by simple lapping, the seating faces on the body must be ground flat and then lapped and the disc replaced by a new one. The total amount of metal removed in this way should not exceed 0.25 mm or 0.010".

When re-assembling, the disc is normally placed in position with the grooved side in contact with the body seating face. Screw on the cap; no gasket is required but suitable high temperature anti-seize grease should be applied to the threads.

To clean or replace the strainer, unscrew the strainer cap using a spanner, withdraw the screen and clean or replace with a new one if damaged. To re-assemble, insert the screen in cap, then screw cap into place. No gasket is required but a fine smear of Molybdenum Disulphide grease should be applied to the threads.



B-85, Phase II, Chakan Indl Area Sawardari, Chakan, Tal. Khed Dist. Pune - 410 501. INDIA Tel : 91(0)2135-393400 A-34/35, MIDC H Block Pimpri, Pune - 411 018. INDIA. Tel : 91(0)20-27442020, 39851199 Fax : 91(0)20-27442040

CIN No.: U28996PN1985PTC037806 www.forbesmarshall.com

© All rights reserved. Any reproduction or distribution in part or as a whole without written permission of Forbes Marshall Pvt Ltd, its associate companies or its subsidiaries ("FM Group") is prohibited.

Information, designs or specifications in this document are subject to change without notice. Responsibility for suitability, selection, installation, use, operation or maintenance of the product(s) rests solely with the purchaser and/or user. The contents of this document are presented for informational purposes only. FM Group disclaims liabilities or losses that may be incurred as a consequence of the use of this information.

